



MAGNI

HEADPHONE AMP AND PREAMP

IN NORSE MYTHOLOGY, MAGNI WAS ONE OF THOR'S SONS.


THIS IS OUR MAGNI. NO RELATION.

YES, WE KNOW, YOU'RE DISSAPPOINTED.

CONSOLE YOURSELF BY KNOWING YOU HAVE
THE BEST AMPLIFIER ANYWHERE NEAR ITS PRICE.

OWNER'S MANUAL

CONNECTIONS



1 Connect your source to the Magni's "IN" RCA jacks with high-quality RCA cables.

2 Connect the supplied wall-wart cable to the jack labeled "AC IN." Do not use any other wall-wart, or Magni will not work.*


3 Optional: Connect the preamp outputs to powered monitors or an external power amp.

4 Turn on the switch. The protection relay will mute the output for about 10 seconds, then it will engage with a click.

5 Select gain. Magni has two gain settings, +15dB (high) and 0dB (low). Low gain gives more volume range for sensitive headphones

*Magni's wall-wart is AC output. Most AC adapters are DC output, and will not work with Magni. Magni works with a 14-16VAC, 1-2A output adapter only.

OPERATION



1 Connect your headphones to the headphone jack. For smaller headphone plugs, you may need a 1/8" to 1/4" adapter (not supplied.)

2 Turn the knob to control volume to both headphone and preamp outputs.

Remember, when you plug headphones in to the Magni, it mutes the preamp output.

And that's it! Enjoy your music!

OVERCURRENT PROTECTION

If your Magni clicks and mutes, then unmutes again, it is protecting itself. This is usually caused by a TRRS headphone plug, shorted headphone cable, or other system problems.*

Check your system, try different headphones and adapters, and learn more about TRRS problems at [schiit.com/trrs](https://www.schiit.com/trrs)

*In extreme cases, at very high volume, you may be running into overload, especially if you are using equalization. This is ridiculously loud and dangerous to your hearing,

IN THE BOX

- (1) Magni
- (1) Wall-Wart
16VAC, 1A

SAFETY PRECAUTIONS



1. If you don't know how to install audio devices, get a qualified professional to help.
2. Never use this device near water, do not expose to rain or moisture, and clean only with a dry cloth.
3. Assure adequate ventilation, do not block ventilation openings, or place near heat sources.
4. Use only the supplied wall-wart or suitable replacement. Route cords away from traffic areas and protect them from being pinched. Unplug the wall-wart from the outlet if the apparatus is unused for a long period of time.
5. To prevent electric shock, do not use the plug with an extension cord, receptacle, or outlet unless blades can be fully inserted.
6. Refer all servicing to qualified service personnel. Service is required when the device has been damaged, including cord or plug damage, liquid has been spilled or objects have fallen into the device, the device has been exposed to rain or moisture, does not operate normally, or has been dropped.

2-YEAR LIMITED WARRANTY

Schiit Audio warrants to the original purchaser that this product shall be free from defects in material and workmanship for two (2) years from the date of purchase. If a defect covered by this warranty occurs during this period, Schiit Audio will repair the defective product, free of charge. Date of purchase will be based on customer receipts, otherwise date of manufacturing will be used.

If you believe you need warranty service, contact us first. Schiit Audio products sent back to us without a Return Authorization (RA) will be returned to the sender without repair. To contact us and obtain an RA, email info@schiit.com.

Warranty Limitations. This warranty shall not apply if a product: (a) is modified or tampered with; (b) is damaged by negligence, accident, unreasonably use, or other causes unrelated to defective materials or workmanship, or (c) has had the serial number altered or removed.

Any implied warranties, including warranties of merchantability and fitness for a particular purpose, are hereby limited in duration to the warranty period of 2 years. In no event shall Schiit Audio be liable for consequential or incidental damages resulting from the breach of any implied or expressed warranties. Some state do not allow these limitations, so they may not apply to you. You may also have other rights which vary from state to state or province to province.



S C H I I T

SCHIIT.COM
INFO@SCHIIT.COM